

i-dose Instruction card



i-team®

i-teamglobal.com

Prepare



1. Load i-dose pods into i-dose dispensing tube.



2. Snap i-dose dispensing tube into special i-dose solution tank.



3. Fill i-dose solution tank with water.



4. Take one pod out of the i-dose dispensing tube.

Dispense



5. Attach i-dose solution tank to i-mop.



6. Open i-dose injector top.



7. Place i-dose pod into i-dose injector. Always place the i-team logo face up.



8. Close i-dose injector lid. Push down yellow button.*

Clean



9. The i-dose solution tank is now filled with properly diluted i-dose solution.



12. Operate the i-mop as usual. The diluted i-dose solution will feed through the brushes/pads for optimum cleaning results.



13. Remove the i-dose solution tank when it's empty.



14. Start the process from #3 again. Refill or replace with a new i-dose solution tank.

*By pushing the yellow button down the pod will be automatically pierced, and causes the i-dose super-concentrated cleaning solution to pour and dissolve into the water in the i-dose solution tank.



faster



cleaner



greener



safer



better